



HANGING INSTRUCTIONS

Surface Preparation

Make sure that the walls are smooth, solid and absolutely dry. Remove all old wallpaper, waterpaint or whitewash and especially any traces of ballpoint ink, aniline pencil or crayon marks. Fill up holes and smooth down.

Powdery, and/or porous surfaces should be sealed with a primer.

ADHESIVE

Use light water base adhesive or other good quality mould resistant PVA-adhesive. Follow manufacturer's instructions

CHECK

That the rolls have the same batch number. For this purpose unroll them approx. 1 metre, and put the rolls overlapping side by side. If you should find any difference in shade or other imperfections, notify your supplier. Do not hang any lengths.

CUTTING OF LENGTHS

Cut the sheets to size: height of wall +5cms. This oversize will cover any differences caused by slanting floors or ceilings.

Number in sequence and mark the top of each length. All references must be hung reversing alternate lengths.

HANGING

Apply an even coat of adhesive on the wall, preferably with a lambswool paint roller.

Smooth each length with plastic spatula or rubber roller.

Overlap the next, revised, length by 3cms and cut down centre of overlap with a sharp knife.

Remove loose strips. Cut the sheets to size along ceiling and skirting.

Remove adhesive stains immediately with damp cloth.

After hanging three lengths look again at the wall result and check material for defects. In case of any imperfections, notify your supplier. Claims that are made afterwards are not accepted.

